

Optirat GenII SOP - Navigating Entryways

For entrances narrower than 40 inches:

1. Rotate the rack so that the smaller dimension of the rack (33.8 inches) is aligned with the door.
2. Remove the protruding column of cages on each side of the rack as shown in Figure 1. It also may be necessary to remove certain column/row ID flags. If your entryway is narrower than 34 inches, it may be necessary to remove the bumpers using a screwdriver.
3. **Carefully move the rack through the door.** Replace cages and any removed column/row ID flags.

For entrances 40 inches or wider, no adjustments are needed.

